## JR PROPO. DMSS 2.4GHz専用



取扱説明書

TELEMETRY SENSOR SERIES

# TLS1-VOL

DUAL MODULATION SPECTRUM SYSTEM

雷圧センサ

このたびは、JR 製品をお買い上げいた

- ・二本のリード線間の電圧差を読み取る方式で、極性はありません。
- 測定も可能。

安全にで使用いただくために必ずお守りください。

使用者もしくは第三者への危害・財産への損害を未然に防止する為、

必ずお守りいただくことを次のように表示します。

お守りいただく内容を、次の表示で区分し説明します。

この表示で「注意事項」を説明します。

この表示で「義務事項」を説明します。

この表示で「禁止事項」を説明します。

♠ 定格電圧以外で使用すると、センサの誤検出や破損の

↑ センサ用リード線接続部は必ず絶縁および防振対策を

↑センサからのハーネスの固定も確実にしてください。ハ

また、ハーネスの根元が切れる可能性があります。

が少ないと誤検出する場合があります。

結露の生じる環境では使用しないこと。

**●**組立後は必ず動作検査を行うこと。

◇分解、改造等をしないこと。

○水に濡らさないこと。

⚠ 飛行中は電池残量に十分注意してください。電池残量

ーネスが絡まって事故の原因となる可能性があります。

## 製品内容

● TLS1-VOL / センサ本体

## 什 様

品 番 TLS1-VOL

検出範囲 DC 0.0~100.0V


動作電圧 4.0V ~ 8.5V

重 量 4 q

長 440mm(リード線長:300mm)

## 構成

## TLS1-VOL



※センサリード線の接続は はんだ付けが必要です。 ケガや火傷に注意し、作業してください。

※本センサは「F-PACK C」には対応しておりません。

※XG7 は対応しておりません。

# 動作確認および注意

- 1. 右図を参考にしてTLS1-VOLを接続します。
- 2. バッテリを接続し、送受信機共電源を"ON"にします。
- 3. 電源投入時はバッテリー等の電圧を検出して、初めて起動します。 ※電源起動時に発生するノイズの為、送信機に表示される 電圧値がおかしくなる場合があります。 その場合は、送信機を操作し、MAX値をクリアしてください。
- 送信機の表示を確認してください。 点灯が確認できない場合は再度センサ線やハーネスの 接続を確認して下さい。

# 【バインドプラグは必ず抜いてご使用ください】


受信機の場合、バインド終了後にバインドプラグを抜かなけ

# 1. センサ線を、測定したい部分に接続します。

置方法

- → 振動でずれたり外れたりしないようにしっかりと固定してください。
- → 振動で接続部がショートしたりしない様必ず絶縁してください。
- 2. TLS1-VOL本体を機体にしっかり固定してください。
  - → センサ線および本体のハーネスが引っかからないようにしっかりと固定してください。
- 3. 本体固定後にTLS1-VOLからのハーネスを受信機のSENS 端子(あるいはDATA 端子)に接続します。
  - → 複数のセンサを接続する場合は、Yハーネス又は、テレメトリーセンサ用アダプタを使用して接続してください。

**■RG731BXの例 → BIND/BATT/SENS 端子 に接続してください**。RG611B等は BATT/DATA 端子に接続してください。



## 配線加工方法

センサ線を電圧の測定をしたい配線に接続します。 動力用バッテリの場合配線図を参考にバッテリ側の配線を 分岐させて接続します。

下図の様にすればバッテリ側の加工無しにバッテリの素電 圧が測定できます。

# TLS1-VOL センサ線は必要な 長さにカットしご使 用下さい。 センサ線はどちらに接続 しても構いません。 レギュレーター ESC 等 (別売) ※振動で接続部が外れたり、ショート したりしない様、熱収縮チューブ等で 必ず絶縁及び防振対策をしてくださ

はんだゴテでのケガや火傷に十分注意してください。

W

## 複数のセンサを接続する場合には・・

TLS1-VOL 以外にも複数のセンサを搭載したい場合には、 TLS1-ADP の使用をご検討ください。

最大 5 種類まで同時接続できるように構成されています。 但し、同じセンサ(同種類を含む)の同時使用は出来ません。 (TL1-PWR/TL1-BVM 等は使用不可)

※ESC:エレクトリックスピードコントローラの略

■ 修理、アフターサービスに関するお問い合わせ

【日本遠隔制御株式会社 ラジコンサービス課】 お問い合せ TEL:06(6732)0200 受付時間/9:00~13:00・14:00~17:30(土・日・祝日及び当社休日を除く)

# http://www.jrpropo.com

修理・アフターサービス・製品に関するお問い合わせ等に関する情報をご案内しています。

日本遠隔制御株式会社 〒577-0809 東大阪市永和2-2-12



だき、誠にありがとうございます。

本製品を正しく安全にご使用いただくために も、取扱説明書を必ずお読みください

にのみ記載します。

【TLロゴについて】 JR テレメトリーシス テムに対応した製品

※本製品はTLロゴ搭載製品専用です。

- ・動力用バッテリー全体の電圧だけでなく、特定のセル間電圧
- 動作確認用のLEDを搭載し、動作確認が容易。
- ※接続ははんだ付け加工が必要となります。

0

0

原因となります。

してください。

ないこと。

● 取扱説明書(本書)

# 送信機での表示について

・TELEMETRYの[F-PACK V]に対応しています。

電圧測定専用となります。

※アラーム設定方法は送信機の取扱説明書をご参照下さい。

- 4. LEDが点灯すれば正常に検出できています。

RG731BXなどのバインド作業にバインドプラグを必要とする れば双方向通信のデータは送信機上に表示されません。 バインドプラグは必ず抜いてで使用ください。





TELEMETRY SENSOR SERIES **TLS1-VOL** 



Voltage Sensor

Thank you for purchasing this JR product.

To allow correct and safe use of this product. be certain to read this operation manual.

This product is exclusively for use with products that incorporate the TL logo.



## Features

- The sensor can be used to measure total voltage, or the voltage of a single cell.
- Because the unit measures voltage difference, there is no polarity requirement for the sensor lead.
- The LED indicates voltage measurement is taking place.
- \* The sensor wire must be soldered to the battery leads or terminals.

## **Product Contents**

• TLS1-VOL / Sensor Main Unit • Operation Manual (this document)


## Specifications

Product Number: TLS1-VOL Detection Range: DC 0.0-100.0V Operating Voltage: 4.0-8.5V

Weight: 4g

Length: 440mm (sensor wire length: 300mm)

## Configuration



\*Note that the sensor lead must be soldered to your point of measurement. Be careful soldering - always have the battery unplugged and remember the soldering iron is hot.

# Transmittor Operation

\*To set a voltage alarm in the transmitter, please refer to the transmitter instruction manual.

\*Note the XG7 does not support telemetry.

# For your safety, be sure to observe the following points

In order to protect against injury to users or third parties, or damage to property, please observe the following.

The information is divided and explained using the following symbols.

"Caution Items" are explained using this indication. 0 "Obligatory Items" are explained using this indication. "Prohibited Items" are explained using this indication.

- ⚠ If the product is used with a voltage other than the rated voltage, it will cause misdetection or damage to the sensor.
- Be sure to securely fix the sensor. In the situation where the sensor comes into contact due to the influence of vibration, damage will be
- Be sure also to securely fix the harness coming from the sensor. If the harness becomes tangled, it may cause an accident. Further, the base of the harness may be cut.
- Pay adequate attention to the remaining battery amount during flights. If the remaining battery amount becomes low, there may be cases where incorrect readings occur.
- Do not use any component which has been damaged, included
- To ensure that the sensor is functioning as desired, please test accordingly. Do not fly until check is complete.
- O Do not disassemble or modify this product.
- Do not get the product wet or damage may be caused. Do not use the product in environments where condensation occurs.

- •Telemetry type: Flight pack voltage [F-PACK V]
- \*This sensor dose not record capacity, it only reads voltage.

# Operation Confirmation and Cautions

- 1. Refer to the drawing on the right to connect the unit.
- 2. After the TLS1-VOL is connected to the receiver (if necessary, using a TLS1-ADP or a Y-harness), turn on the power to the receiver.
- 3. The sensor will activate automatically. **Note:** Occasionally noise generated by the motor may cause a high maximum voltage to be recorded - simply reset (clear) the maximum value on the transmitter to obtain correct values.
- 4. If the LED glows, the voltage is being sensed correctly. Please check the transmitter indications. If the LED does not glow, check the wire connections including

the sensor communications harness.

**IMPORTANT:** Be sure to remove the bind plug prior to use. With receivers such as the RG731BX or RG831B which require a bind plug, be sure to remove the bind plug from the receiver prior to use as it interferes with the bi-directional communications, and telemetry data will not be displayed on the LCD screen.

## 3. After fixation of the TLS1-VOL to the aircraft, connect the sensor communications harness to the receiver's "SENS" or "DATA" port.

Note: Be sure that none of the wires or connectors contact the moving components.

2. Be certain to securely mount the sensor to the aircraft.


1. Attach the sensor wires to the electric power source wires - polarity does not matter.

Installation Method

Note: Use either a Y-harness or TLS1-ADP to connect the sensor communications harness to the receiver. If there is an empty slot available on the receiver, connect the battery connection to the empty slot, and connect the sensor communications harness to the "SENS" or "DATA" slot.

Note: Be sure to attach the wires securely, by carefully soldering the connections. Be sure to use heat shrink tube or insulation tape to avoid short circuits.

## ■ RG731BX Connection Example→ Connect to the BIND/BATT/SENS terminal



# Wiring

To measure main power pack voltage, solder the sensor lead to the objective lines as shown in the figure below. Using this method, your battery pack does not need to be modified.

# TLS1-VOL The sensor leads can be shortened Note: Polarity of the sensor as necessary. wires is not important. Regulator, ESC, etc.. Note: Be sure to insulate the sensor leads with heat shrink tube or insulation tape to avoid short circuits, or the solder joints breaking with vibration.



Be careful handling the soldering iron.

## Notes:

- 1. When you are using a 2s LiPo and regulator to supply vour receiver, you may use the TLS1-VOL to measure true receiver battery voltage (indicated as F-PACK-V on the transmitter). The TLS1-VOL can be wired into the switch harness before the regulator.
- 2. An alternative method of connecting the TLS1-VOL to your battery is to plug it into your LiPo balance connector (measuring either single cell or whole pack voltage).
- 3. When multiple sensors are to be connected... When you wish to incorporate several sensors in addition to the TLS1-VOL, please use the optional the TLS1-ADP. This adaptor is configured to allow simultaneous connection of up to five sensor types. However, it is not possible to use more than one of the same sensor type at the same time.
- For further questions or inquiries please contact your local dealer or JR distributor in your country.

http://www.jrpropo.com

